

1949-52 Bumpers, Bumper Bolts, Bumper Bolt Kits

1949-52 FRONT 1-PIECE BUMPER

Chromed and ready to install!

ORDER #6482

\$350⁰⁰

New



1949-52 REAR 1-PIECE BUMPER

Just like the front — ready to go

ORDER #6483

\$350⁰⁰

New



HIGH DOME BUMPER BOLT

Original bumper bolt used on cars.
Chrome finish.

ORDER #520HD

\$4⁰⁰ ea.



1/2" POLISHED STAINLESS CAP BUMPER BOLT

ORDER #520 **\$2⁰⁰** ea.



FRONT OR REAR BUMPER BOLT KIT

Uses replacement
1/2" stainless capped bolt.
Bolt is not stainless.

ORDER #1917

\$10⁰⁰ ea.



FRONT OR REAR BUMPER BOLT KIT

Uses original high dome bolt.

ORDER #1904

\$16⁰⁰



1949-52 FRONT BUMPER ASSEMBLY KIT

ORDER #5905

\$24⁰⁰

1949-52 REAR BUMPER ASSEMBLY KIT

ORDER #1902

\$24⁰⁰



1949-52 FRONT BUMPER ASSEMBLY KIT

Uses replacement 1/2" steel bolt with stainless cap.

ORDER #5905-1

\$16⁰⁰

REAR BUMPER ASSEMBLY KIT

ORDER #1919

\$16⁰⁰



REAR BUMPER ARM GROMMETS

ORDER #4601-9

\$9⁰⁰ pr.



FRONT SPLASH PAN PLUG

ORDER #4601-10

\$6⁰⁰ pr.



1949-50 FRONT LICENSE POCKET GUARD

Excellent reproduction.

ORDER #4540

\$150⁰⁰



1953-54 Bumpers, Bumper Bolts, Bumper Bolt Kits

1953 1-PIECE FRONT BUMPER

Chrome plated, excellent quality
- ready to install.

ORDER #482



\$375⁰⁰

1954 1-PIECE FRONT BUMPER

Ready to install.

ORDER #483

\$375⁰⁰



1953 or 1954 1-PIECE REAR BUMPER

Chromed and ready to install.

ORDER #484



\$375⁰⁰



1/2" HIGH DOME CHROME BUMPER BOLT

Original bumper bolt used on cars.
Chrome finish.

ORDER #520 HD **\$4⁰⁰** ea.



1/2" POLISHED STAINLESS CAP BUMPER BOLT

ORDER #520 **\$2⁰⁰** ea.



FRONT OR REAR BUMPER BOLT KIT

Uses original high dome bolt.

ORDER #1904
\$16⁰⁰



FRONT OR REAR BUMPER BOLT KIT

Uses replacement 1/2" stainless capped bolt. Bolt is not stainless.

ORDER #1917
\$10⁰⁰

1953 OR 1954 FRONT BUMPER ASSEMBLY KIT

ORDER #1902

\$24⁰⁰



1953 - 1954 REAR BUMPER ASSEMBLY KIT

ORDER #1901
\$24⁰⁰

1953-1954 FRONT CLIP ASSEMBLY KIT

Contains all bolts, nuts, washers, etc.
to reassemble front clip.
(Fenders, inner fenders)

ORDER #1905 **\$20⁰⁰**



1953 OR 1954 FRONT BUMPER ASSEMBLY KIT

Uses replacement 1/2" stainless capped bolt. Bolt is not stainless.

ORDER #1918 **\$16⁰⁰**



1953 OR 1954 REAR BUMPER

Cap only assembly kit.

ORDER #1919
\$16⁰⁰

