

# 1949-52 BRAKES



**1949-50 FRONT  
BRAKE SHOES**  
ORDER #5401

**\$45<sup>00</sup>** set

**1949-50 REAR  
BRAKE SHOES**  
ORDER #5402

**\$45<sup>00</sup>** set

## BRAKE SHOES

Replace worn shoes with solid new shoes.

**1951-52 FRONT  
BRAKE SHOES**  
ORDER #1401

**\$38<sup>00</sup>** set

**1951-52 REAR  
BRAKE SHOES**  
ORDER #1402

**\$38<sup>00</sup>** set

## BRAKE SHOE HOLD DOWN SPRING KIT



Each kit will do 2 wheels.  
Need 2 sets per car.

**1951-52 KIT**  
ORDER #1416

**\$12<sup>00</sup>** set



## 1951-52 BRAKE DRUM

New replacement.  
Ready to install.  
Fits all models.

ORDER #1427

**\$67<sup>00</sup>** ea.

## BRAKE ADJUSTING HOLE PLUG

2 sets needed for  
1949-50 cars.  
1 set needed for  
1951-52 cars.



ORDER #1429

**\$5<sup>00</sup>** set of 4

## BRAKE SHOE RETURN SPRINGS



**1949-50.** Sold in pairs.  
Requires 4 springs per car.

ORDER #5403

**\$12<sup>00</sup>** pr.



**1951-52.**  
Sold in 4 per package.  
Requires 8 per car.

ORDER #1423

**\$11** set of 4

## BRAKE ADJUSTING SCREW SPRING

Requires 4 per car for 1951-52 models.

ORDER #1430

**\$7<sup>00</sup>** ea.



## BRAKE ADJUSTOR SCREW

1951-52 models. Sold separately. Requires 4 per car.



ORDER #1421

**\$12<sup>00</sup>** ea.

## BRAKE BLEEDER SCREW

Requires 4  
per car for  
1949-52  
models.



ORDER  
#1447

**\$2<sup>00</sup>** ea

## BRAKE PEDAL RETURN SPRING

Connects to frame and  
brake pedal to return  
brake after use.

ORDER #1456 **\$10<sup>00</sup>**



## 1949-52 BRAKE AND CLUTCH PAD

Replace worn pads with  
new pads.  
Looks great!

ORDER #4702

**\$6<sup>00</sup>** ea.

## BRAKE LIGHT SWITCH

Exact reproduction.

**1949-50 SWITCH** **\$22<sup>00</sup>**  
ORDER #5332

**1951-52 SWITCH** **\$22<sup>00</sup>**  
ORDER #1332



## 1949-52 EMERGENCY BRAKE HANDLE

ORDER #5407

**\$28<sup>00</sup>** ea.



# MASTER CYLINDER AND RELATED PARTS

## 1950-54 POWERGLIDE CONVERSION KIT

Convert your standard master cylinder to powerglide. Kit is easy to install.

Instructions included.

ORDER #1422-KIT

**\$43<sup>00</sup>**



## 1950-54 CHEV PEDAL SHAFT LOCK PIN (STANDARD TRANSMISSION)

Machined and heat treated pin that holds the brake and clutch pedals in the Master Cylinder.



ORDER #1449 **\$35<sup>00</sup>**

## 1950-54 CHEV PEDAL SHAFT LOCK PIN (POWERGLIDE TRANSMISSION)

This machined and heat treated part holds the brake pedal in the Master Cylinder.



ORDER #1448 **\$35<sup>00</sup>**

## 1953-54 STANDARD TRANSMISSION MASTER CYLINDER

Brand new master cylinder to replace what can't be rebuilt. Fits cars with standard transmission only.

Rebuilt also available.

ORDER #1422 **\$135<sup>ea.</sup>**



## 1949-52 MASTER CYLINDER

Brand new master cylinder to replace what can't be rebuilt. Powerglide cars will need to use the standard transmission master cylinder with a conversion kit.



1949-52 STANDARD TRANSMISSION MASTER CYLINDER ORDER #5405

**\$135<sup>00</sup>**



1950-52 POWERGLIDE MASTER CYLINDER ORDER #5422PG

**\$175<sup>00</sup>**

## 1953-54 POWERGLIDE TRANSMISSION MASTER CYLINDER CONVERSION

Need a master cylinder for your powerglide equipped car?

We've come up with the solution to your problem!

Install a **brand new** standard transmission master cylinder with all the hardware to convert it to fit in your car.

(Includes instructions)



ORDER #1422PG **\$175<sup>00</sup>**

## MASTER CYLINDER REBUILD KIT

Contains all needed parts to rebuild Master Cylinder

1949-52 ORDER #5406

1953-54 ORDER #1403

**\$30<sup>00</sup>**



## 1949-54 MASTER CYLINDER PLATE COVER GASKET

ORDER #1445

**\$4<sup>00</sup> ea.**



## 1949-54 MASTER CYLINDER COVER

Just like original.

ORDER #712

**\$12<sup>00</sup>**



# BRAKE HOSES, CLIP, JUNCTION BLOCK

## 1951-54 REAR BRAKE HOSE JUNCTION BLOCK

Replace that worn junction block with one that will last for 40 more years.

ORDER #1417 **\$48<sup>00</sup>**



## BRAKE HOSES

Replace brittle hoses with fresh ones that won't break if you touch them.

**\$19<sup>00</sup> ea.**



1949-50 FRONT HOSE

(Requires 2)

ORDER #5404F

1949-50 REAR HOSE

(Requires 1)

ORDER #5404R

1951-52 FRONT HOSE

(Requires 2)

ORDER #1404F

1951-52 REAR HOSE

(Requires 1)

ORDER #1404R

1953-54 FRONT HOSE

(Requires 2)

ORDER #1404F

1953-54 REAR HOSE

(Requires 1)

ORDER #1404R

## 1949-54 BRAKE HOSE RETAINING CLIP

ORDER #1419 **\$3<sup>00</sup> ea.**

Sold separately. Requires 3 per car.

