TRANSMISSION, CLUTCH & SPEEDOMETER

3-SPEED FLOOR SHIFT KIT

Designed to fit your 1949-54 exclusively – not a universal fit. Shifter does not interfere with the seat and shift pattern fits the car perfectly. Preassembled, easy to install and instructions are included.

1949-52 ORDER # 7105-1

1953-54 ORDER # 7105

* Not for convertibles

TRANSMISSION REBUILD KIT

Includes all wet and dry gaskets and clutches. For powerglide (automatic) transmission.



1950-54 Chev **ORDER #7178**



1949-53 CLUTCH KIT

Kit includes precision matched clutch, disc, release bearing, pilot bushing, lubricant. 9" clutch disc.



1952-54 TRANSMISSION MOUNT

(REAR MOTOR MOUNT)

This usually needs replacement, especially on cars with powerglide.

POWERGLIDE ORDER #1108 STANDARD TRANSMISSION ORDER #1108S





1949-54 SHIFT ROD **GROMMET**

(with metal lining)

ORDER #1468

\$400

DICE SHIFT KNOB

About 2" square with rounded corners. Comes with size adaptors & wrench.

ORDER #2139R RED **ORDER #2139BU BLUE**

ORDER #2139W WHITE BLACK

ORDER #2139BK



SKULL SHIFT KNOB

Heavy cast metal with chrome finish and red eyes. Has size adapters and allen wrench.

ORDER #2138



1949-1954 PARTS CATALOG